



A Division of Thiessen Products, Inc.

# INSTRUCTION SHEET FOR TOOL No. 1707

## SPREADING TOOL

USE ON ALL 1980-2001 RUBBER MOUNT BIG TWIN, EXCEPT DYNAS



1. Refer to H-D® Service Manual for specifications.
2. Install clevebloc spreading tool between swing arm cleveblocs. Lube all threads.
3. Turn nuts with a 7/8" wrench to spread the cleveblocks apart to approximately 4.600 inch.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS AND TOOL.  
 SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.  
 THE LAST TOOLS YOU WILL EVER NEED TO BUY.

***"Doing It Right... The JIMS Way!"***

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224  
VISIT US ON THE WEB AT [WWW.JIMSUSA.COM](http://WWW.JIMSUSA.COM)



A Division of Thiessen Products, Inc.

# INSTRUCTION SHEET FOR TOOL No. 1707

## SPREADING TOOL

USE ON ALL 1980-2001 RUBBER MOUNT BIG TWIN, EXCEPT DYNAS



1. Refer to H-D® Service Manual for specifications.
2. Install clevebloc spreading tool between swing arm cleveblocs. Lube all threads.
3. Turn nuts with a 7/8" wrench to spread the cleveblocks apart to approximately 4.600 inch.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS AND TOOL.  
 SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS.  
 THE LAST TOOLS YOU WILL EVER NEED TO BUY.

***"Doing It Right... The JIMS Way!"***

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224  
VISIT US ON THE WEB AT [WWW.JIMSUSA.COM](http://WWW.JIMSUSA.COM)