



A Division of Thiessen Products, Inc.

INSTRUCTION SHEET FOR TOOL #2233



TAPPET SCREEN PLUG REMOVER

1. Refer to H-D® Service Manual for specifications.
2. Using a 3/4" open end wrench, turn plug counter clock wise to remove plug. Most exhaust systems do not have to be removed. Can be used to remove other slot type plugs.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

"From the Track... To the Street!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224



A Division of Thiessen Products, Inc.

INSTRUCTION SHEET FOR TOOL #2233



TAPPET SCREEN PLUG REMOVER

1. Refer to H-D® Service Manual for specifications.
2. Using a 3/4" open end wrench, turn plug counter clock wise to remove plug. Most exhaust systems do not have to be removed. Can be used to remove other slot type plugs.

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

"From the Track... To the Street!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224