



## INSTRUCTION SHEET FOR #2362



### EXTERNAL LOCK RING PLYERS USE ON ALL MODELS

Refer to H.D.® Service Manual for specifications.

1. Use to remove external snap rings. Tool has jaws that are scored on the outside to hold rings securely on removal and installation, always replace retaining rings.

**CAUTION:** WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

***"FROM THE TRACK... TO THE STREET!"***

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-7422



## INSTRUCTION SHEET FOR #2362



### EXTERNAL LOCK RING PLYERS USE ON ALL MODELS

Refer to H.D.® Service Manual for specifications.

1. Use to remove external snap rings. Tool has jaws that are scored on the outside to hold rings securely on removal and installation, always replace retaining rings.

**CAUTION:** WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

***"FROM THE TRACK... TO THE STREET!"***

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-7422