



Instruction Sheet For Tool No.2387

Sprocket Shaft Seal Installer

Use on Sportster 1986-94 & Buel I® 1987-94

Use to install sprocket shaft seal in crankcase to the proper depth.
For holding the seal perfectly square, use driver handle No.2256.



1. Please refer to H.D.® Service Manual for specifications.
2. Place sprocket seal over shoulder of seal driver, with lips of seal facing downward.
3. Center tool over bearing bore and drive seal into bore with rubber hammer until seal driver contacts base of crankcase.

CAUTION: Wear safety glasses. Excessive force may damage the parts !
See JIMS® catalog for over 100 other top quality professional tools.
The last tools you will ever need to buy.

"From the Track... To the Street!"

555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422