



INSTRUCTION SHEET FOR #33416-80



RACE AND BEARING INSTALLING TOOL HANDLE

Use with JIMS® tool No's. 33071-73, 2232, 34810-84, 788, 94547-80A&B, 97272-60 and 97273-60. Use a press fit lube.

If a press is not available, it is highly recommended that you use a JIMS® No.1080 brass hammer.

PARTS AVAILABLE SEPARATELY			
No.	Qty.	Description	Part No.
1	1	O-RING	2310

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

"From the Track... To the Street!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224



INSTRUCTION SHEET FOR #33416-80



RACE AND BEARING INSTALLING TOOL HANDLE

Use with JIMS® tool No's. 33071-73, 2232, 34810-84, 788, 94547-80A&B, 97272-60 and 97273-60. Use a press fit lube.

If a press is not available, it is highly recommended that you use a JIMS® No.1080 brass hammer.

PARTS AVAILABLE SEPARATELY			
No.	Qty.	Description	Part No.
1	1	O-RING	2310

CAUTION: WEAR SAFETY GLASSES. EXCESSIVE FORCE MAY DAMAGE PARTS! ,SEE JIMS® CATALOG FOR OVER 100 OTHER TOP QUALITY PROFESSIONAL TOOLS. THE LAST TOOLS YOU WILL EVER NEED TO BUY.

"From the Track... To the Street!"

555 DAWSON DRIVE, CAMARILLO, CA 93012 • PHONE 805-482-6913 • FAX 805-482-9224